


November 2010

Value Express Hinge Adjustments



Adjust the Hinges by Turning the Following Screws:

- 1 – Vertical Adjustment, Up and Down
- 2 – Depth Adjustment, In and Out
- 3 – Horizontal Adjustment, Left and Right